

XR-EMV300

SERVICE MANUAL



E Model

Ver 1.0 2003.08

- XR-EMV300 is composed of following models.
As for the service manual, it is issued for each component model, then, please refer to them.

COMPONENT MODEL NAME

	XR-EMV300
VIDEO CD DECK RECEIVER SYSTEM	CX-LEMV300
SPEAKER SYSTEM	SX-LEMV300

PARTS LIST

<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
	ACCESSORIES *****	
1-478-047-11	REMOTE COMMANDER (RM-Z20026)	
1-501-374-92	ANTENNA, LOOP (AM)	
△ 1-569-008-12	ADAPTOR, CONVERSION 2P (SP, MY)	
1-751-619-13	CORD, CONNECTION (COAXIAL DIGITAL CORD)	
1-793-184-21	CONNECTOR (F TYPE ADAPTOR)(TH)	
1-793-184-23	CONNECTOR (F TYPE ADAPTOR)(SP,MY)	
4-248-992-11	MANUAL, INSTRUCTION (ENGLISH, SPANISH, FRENCH, CHINESE)(SP, MY)	
4-248-992-41	MANUAL, INSTRUCTION (ENGLISH, THAI)(TH)	
4-249-131-01	COVER BATTERY (FOR RM-Z20026)	

- Abbreviation
MY : Malaysia model.
SP : Singapore model.
TH : Thai model.

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

MICRO HI-FI COMPONENT SYSTEM

9-961-060-01
2003H16-1
© 2003.08

Sony Corporation
Home Audio Company
Published by Sony Engineering Corporation

