

DAV-FC8/FC9

SERVICE MANUAL



Ver 1.0 2003.08

US Model

DAV-FC8/FC9

Canadian Model

DAV-FC9

- DAV-FC8/FC9 are composed of following models.
As service manuals are issued for each component model, please refer to them.

COMPONENT MODEL NAME

	DAV-FC8	DAV-FC9
SACD/DVD RECEIVER	HCD-FC8	HCD-FC9
PACKAGE SPEAKER	SS-SC6	SA-SC8
FRONT SPEAKER	SS-TS6	SS-TS8
SURROUND SPEAKER	SS-TS7	SS-TS8
CENTER SPEAKER	SS-CT6	SS-CT8
SUB WOOFER	SS-WS6	SA-WS8

PARTS LIST

Part No.	Description	Remark
	ACCESSORIES	

1-478-143-11	COMMANDER, STANDARD (RM-SP900)	
1-754-059-12	ANTENNA, LOOP (AM)	
1-754-147-11	ANTENNA (FM)	
1-765-388-13	CORD, CONNECTION (PIN-PIN)	
	(SUB WOOFER CORD)(FC9:US,CND)	
1-769-108-11	CORD, CONNECTION (VIDEO CORD)	
1-827-243-11	CORD (WITH CONNECTOR)	
3-084-601-01	COVER, BATTERY (FOR RM-SP900)	
4-248-451-11	MANUAL, INSTRUCTION (ENGLISH)(FC8:US)	
4-248-451-11	MANUAL, INSTRUCTION (ENGLISH)(FC9:US,CND)	
4-248-454-21	MANUAL, INSTRUCTION (FRENCH)(FC9:CND)	

- Abbreviation
CND : Canadian model.

COMPACT AV SYSTEM

SONY®

9-961-133-01
2003H16-1
© 2003.08

Sony Corporation
Home Audio Company
Published by Sony Engineering Corporation

