

DAV-SC5/SC6/SC8

SERVICE MANUAL



Ver 1.0 2003.09

- DAV-SC5/SC6/SC8 are composed of following models.
As service manuals are issued for each component model, please refer to them.

AEP Model

UK Model

E Model

DAV-SC5/SC6/SC8

Australian model

DAV-SC6/SC8

COMPONENT MODEL NAME

	DAV-SC5	DAV-SC6	DAV-SC8
SACD/DVD RECEIVER	HCD-SC5	HCD-SC6	HCD-SC8
PACKAGE SPEAKER	SS-WT5	SS-SC6	SA-SC8
FRONT SPEAKER	SS-TS5	SS-TS6 (EXCEPT AEP, UK) SS-TS8 (AEP, UK)	SS-TS8
SURROUND SPEAKER	SS-TS5	SS-TS7 (EXCEPT AEP, UK) SS-TS5 (AEP, UK)	SS-TS8
CENTER SPEAKER	SS-CT5	SS-CT6 (EXCEPT AEP, UK) SS-CT8 (AEP, UK)	SS-CT8
SUB WOOFER	SS-WS5	SS-WS6	SA-WS8

- Abbreviation
 AUS : Australian model.
 E32 : 110-240V AC area in E model.
 EA : Saudi Arabia model.
 MX : Mexican model.
 KR : Korea model.
 RU : Russian model.
 SP : Singapore model.
 TW : Taiwan model.

PARTS LIST

Part No.	Description	Remark	Part No.	Description	Remark
	ACCESSORIES *****		4-248-413-11	MANUAL, INSTRUCTION (ENGLISH)(SC6:AUS, SP)	
			4-248-413-21	MANUAL, INSTRUCTION (TRADITIONAL CHINESE)(SC6:SP)	
1-477-370-13	COMMANDER, STANDARD (RM-SS880)	(SC5:RU/SC8:MX)	4-248-413-31	MANUAL, INSTRUCTION (KOREAN)(SC6:KR)	
1-478-142-11	COMMANDER, STANDARD (RM-SP800)	(SC5:EXCEPT RU/SC6/SC8:EXCEPT MX)	4-248-413-41	MANUAL, INSTRUCTION (ENGLISH, RUSSIAN)(SC6:RU)	
△ 1-569-008-12	ADAPTOR, CONVERSION 2P (E32)		4-248-415-11	MANUAL, INSTRUCTION (ENGLISH)(SC6:AEP, UK)	
1-754-059-12	ANTENNA, LOOP (AM)(AEP, UK)		4-248-415-21	MANUAL, INSTRUCTION (FRENCH, GERMAN, SPANISH)(SC6:AEP)	
1-754-060-13	ANTENNA (FM)		4-248-415-31	MANUAL, INSTRUCTION (DUTCH, SWEDISH, ITALIAN, POLISH)(SC6:AEP)	
1-754-149-11	LOOP ANT (AM)(EXCEPT AEP, UK)		4-248-415-41	MANUAL, INSTRUCTION (DANISH, FINNISH, PORTUGUESE)(SC6:AEP)	
1-765-388-13	CORD, CONNECTION (PIN-PIN)(SUB WOOFER CORD)(SC8)		4-248-415-51	MANUAL, INSTRUCTION (GREEK)(SC6:AEP)	
1-769-108-11	CORD, CONNECTION (VIDEO CORD)		4-248-417-11	MANUAL, INSTRUCTION (ENGLISH)(SC8:TW, AUS, E32, EA, SP)	
△ 1-770-783-21	CONNECTOR, CONVERSION (UK, RU)		4-248-417-21	MANUAL, INSTRUCTION (FRENCH)(SC8:E32, EA)	
1-827-243-11	CORD (WITH CONNECTOR)(SC5/SC6)		4-248-417-31	MANUAL, INSTRUCTION (SPANISH)(SC8:E32)	
1-827-244-11	CORD (WITH CONNECTOR)(SC8)		4-248-417-41	MANUAL, INSTRUCTION (ARABIC)(SC8:EA)	
4-248-406-11	MANUAL, INSTRUCTION (ENGLISH)(SC5:AEP, UK)		4-248-417-51	MANUAL, INSTRUCTION (TRADITIONAL CHINESE)(SC8:E32, SP, TW)	
4-248-406-21	MANUAL, INSTRUCTION (FRENCH, GERMAN, SPANISH)(SC5:AEP)		4-248-417-61	MANUAL, INSTRUCTION (KOREAN)(SC8:KR)	
4-248-406-31	MANUAL, INSTRUCTION (DUTCH, SWEDISH, ITALIAN, POLISH)(SC5:AEP)		4-248-417-71	MANUAL, INSTRUCTION (ENGLISH, RUSSIAN)(SC8:RU)	
4-248-406-41	MANUAL, INSTRUCTION (DANISH, FINNISH, PORTUGUESE)(SC5:AEP)		4-248-418-11	MANUAL, INSTRUCTION (ENGLISH)(SC8:AEP, UK)	
4-248-406-51	MANUAL, INSTRUCTION (GREEK)(SC5:AEP)		4-248-418-21	MANUAL, INSTRUCTION (FRENCH, GERMAN, SPANISH)(SC8:AEP)	
4-248-408-11	MANUAL, INSTRUCTION (ENGLISH)(SC5:E32, EA, HK, SP, TW, KR)		4-248-418-31	MANUAL, INSTRUCTION (DUTCH, ITALIAN, SWEDISH, POLISH)(SC8:AEP)	
4-248-408-21	MANUAL, INSTRUCTION (FRENCH)(SC5:E32, EA)		4-248-418-41	MANUAL, INSTRUCTION (DANISH, FINNISH, PORTUGUESE)(SC8:AEP)	
4-248-408-31	MANUAL, INSTRUCTION (SPANISH)(SC5:E32)		4-248-418-51	MANUAL, INSTRUCTION (GREEK)(SC8:AEP)	
4-248-408-41	MANUAL, INSTRUCTION (ARABIC)(SC5:EA)		3-084-601-01	COVER, BATTERY (FOR RM-SP800/SS880)	
4-248-408-51	MANUAL, INSTRUCTION (TRADITIONAL CHINESE)(SC5:E32, HK, SP, TW)				

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

COMPACT AV SYSTEM

SONY®

9-961-136-01

2003116-1

© 2003.09

Sony Corporation

Home Audio Company

Published by Sony Engineering Corporation